

EN SAFETY INSTRUCTIONS - PART B

This manual B contains definitions of all potentially applicable parameters & specifications with icons, as per the manual A... Always read all technical specifications of the product. Verify stated icons on the identification label on the product and icons shown in Part A of these safety instructions.


28- The product is only suitable for reflector bulbs. 29- The product is only suitable for CFL-I, or LED-bulbs (e.g. E14, E27, Gu10, Gx53, ...). 30- The product is not suitable for CFL-I, or LED-bulbs (e.g. E14, E27, Gu10, Gx53, ...). 31- Only a bulb with a diameter of 60 mm can be used. A bulb with a 45 mm diameter must not be used for this product.

簡符號, 代表產品適用於歐洲指令 2012/19/EC. 請取得當地電氣及電子產品廢棄物棄置、分類及收集系統的相關資訊. 請根據當地法規處理, 請勿將廢棄產品當作一般家庭垃圾棄置. 正確處理廢棄產品有助於避免對環境和人類健康造成負面影響.

37- 이 제품은 기본 제공된 조광기 혹은 집의 전기 설비에 연결된 (포함되지 않은) 조광기를 사용하여 조광이 가능합니다. 38- 이 제품은 안전 변압기와 함께 작동합니다. 항상 안전 변압기는 같은 기술 사양을 가진 변압기로 교체하십시오.

11- IPX3: Produkt in dapat terpapar dari tetesan hujan (tetesan hujan di bawah sudut maksimum 60° terhadap sumbu vertikal). 12- IPX4: Produk in tahan cipratan air: produk dapat terpapar dari cipratan air sesuai arah (360°). 13- IPX5: Produk in terlindungi dari jet air.





English:

To avoid corrosion, clean the luminaire a minimum of 2 times per year with a soft cloth and a neutral detergent. (4 times in coastal or industrial areas)

简体中文:

为避免灯具腐蚀, 请用软布和中性洗涤剂每年至少清洁两次(沿海地区或工业集中区域至少四次).

繁體中文:

為避免燈具腐蝕, 請用軟布和中性洗滌劑每年至少清洗兩次(海邊和工業區域至少四次).